

Continental TSB 2023-1129A

Latest Technology REDI-Sensor™ TPMS Sensors Require TPMS Tool Update and New Sensor Configuration Process

- An up-to-date compatible TPMS tool is required to configure the proper communication protocol.
- Even brand-new tools may have outdated software; and some current TPMS Tools do not support our latest technology.

Four New REDI-Sensor™ Part Numbers Include



▪ SE10008

▪ SE10006

▪ SE10007

▪ SE10005

Step 1 | Confirm TPMS Tool Compatibility using list below

- | | | |
|------------------------------|----------------------|---------------------|
| ▪ Continental Autodiagnos D | ▪ ATEQ VT36 | ▪ SCHRADER S57 |
| ▪ Continental Autodiagnos SE | ▪ BARTEC Tech300PRO | ▪ SNAP-ON TPMS5 |
| ▪ ATEQ VT67 | ▪ BARTEC Tech400PRO | ▪ SNAP-ON TPMS4 |
| ▪ ATEQ VT57 | ▪ BARTEC Tech450PRO | ▪ MATCO MAXTPMS 2.0 |
| ▪ ATEQ VT56 | ▪ BARTEC Tech500PRO | ▪ MATCO MD56 |
| ▪ ATEQ VT47 | ▪ BARTEC Tech550PRO | ▪ MATCO MAXTPMS 3.0 |
| ▪ ATEQ VT46 | ▪ BARTEC Tech600PRO | ▪ COSTCO VT56 |
| ▪ ATEQ VT41 | ▪ BARTEC TechRitePRO | ▪ DILL D48 |
| ▪ ATEQ VT37 | ▪ SCHRADER S56 | ▪ OTC 3838 |
| ▪ HUF DT56 | ▪ TOPDON TP-47 | ▪ NAPA 92-1541 |
| | | ▪ NAPA 92-1551 |

Step 2 | Verify TPMS Tool has latest manufacturer software update

www.redi-sensor.com/updates or call our Tech Support at 800-265-1818 for assistance.

Step 3 | Follow new TPMS sensor configuration process

For new sensor configuration process instructions see next page or visit:

www.redi-sensor.com/updates or call our Tech Support at 800-265-1818 for assistance.



How to Videos

Public

Latest Technology REDI-Sensor™ TPMS Sensor Configuration Process

<u>Autodiagnos TPMS D and SE Tool</u> <i>For REDI-Sensor SE10005, SE10006</i> Includes customized software to auto-configure REDI-Sensors during the relearn procedure	
<p style="text-align: center;"><u>ATEQ VT56, VT37, VT41, VT46, VT47 or equivalent</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>ATEQ Relearn</p> <ol style="list-style-type: none"> 1. Select Service or Service TPMS 2. Select Make/Model/Year or VIN scan 3. Select Relearn 4. Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>ATEQ Configure Sensor</p> <ol style="list-style-type: none"> 1. Select Program 2. Select Sensor 3. Select REDI-Sensor 4. Select Make/Model/Year <ol style="list-style-type: none"> a. Select Trigger to unlock protocol b. Repeat 'a' for each new REDI-sensor c. Return to Main menu, proceed to Relearn <p>ATEQ Relearn</p> <ol style="list-style-type: none"> 1. Select Service 2. Select Make/Model/Year or VIN scan 3. Select Relearn 4. Trigger sensors following Relearn procedure 	<p style="text-align: center;"><u>Bartec Tech300Pro/Pro C, Tech400Pro, Tech500Pro, Tech450Pro, Tech550Pro, Tech600Pro and TechRitePro</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Bartec Relearn</p> <ol style="list-style-type: none"> 1. Select New TPMS Service 2. Select Make/Model/Year or VINdicade 3. Relearn: OBD, Stationary, or Drive 4. Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Bartec Relearn</p> <ol style="list-style-type: none"> 1. New TPMS Service 2. Make/Model/Year or VINdicade 3. Program Sensors Menu <ol style="list-style-type: none"> a. REDI-Sensor to Unlock protocol b. Repeat for each sensor as needed c. Return to previous menu 4. Relearn: OBD, Stationary, or Drive 5. Trigger sensors following Relearn procedure
<p style="text-align: center;"><u>Snap-On TPMS4</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Relearn</p> <ol style="list-style-type: none"> 1. Select Relearn 2. Select Make/Model/Year 3. Select Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Configure Sensor</p> <ol style="list-style-type: none"> 1. Select Special Functions 2. Select REDI-Sensor Unlock 3. Select Make/Model/Year <ol style="list-style-type: none"> a. Trigger to Unlock protocol b. Repeat for each sensor as needed. c. Return to previous menu <p>Relearn</p> <ol style="list-style-type: none"> 1. Select Relearn 2. Select Make/Model/Year 3. Trigger sensors following Relearn procedure 	<p style="text-align: center;"><u>Snap-On TPMS5</u></p> <p><i>For REDI-Sensor SE10005, SE10006</i></p> <p>Relearn</p> <ol style="list-style-type: none"> 1. Select TPMS 2. Select Make/Model/Year 3. Select Relearn 4. Trigger sensors following Relearn procedure <p><i>For REDI-Sensor SE10007, SE10008</i></p> <p>Relearn</p> <ol style="list-style-type: none"> 1. Select TPMS 2. Select Make/Model/Year 3. Select Replace 4. Select REDI-Sensor <ol style="list-style-type: none"> a. Trigger to Unlock Protocol b. Repeat for each sensor as needed 5. Select Relearn 6. Trigger sensors following Relearn procedure

Public